




Instructions:
Include Transformer for 480V systems only.



Instructions:
Select Pump 1 Panel Interior Layout from Sheets DS-19.1.1, DS-19.1.2, DS-19.1.3, based on Motor Starter Type.



TBP1 LAYOUT
3044102 - 23
3047028 - 1
3044128 - 2



TBP1A LAYOUT
3044160 - 4
3047028 - 1

SEE NOTE #10 ON SHEET DS-0.1