



Instructions:
 Include Transformer for 480V systems only.

Instructions:
 Select Pump 2 Panel Interior Layout from Sheets DS-19.2.1, DS-19.2.2, DS-19.2.3, based on Motor Starter Type.



TBP2 LAYOUT

3044102 - 23
 3047028 - 1



TBP2A LAYOUT

3044160 - 4
 3047028 - 1

Pump 2 Panel - Interior Layout - RVSS.dwg



SHEET NO.
DS-19.2.2

DATE: 9/01/2016

SEE NOTE #10 ON SHEET DS-0.1